



Are you using an Intel® Viiv™ technology-based PC? If so, before configuring your AirStation WZR-AG300NH Nfiniti wireless router, you need to disable WPS on the unit. Follow the instructions below to disable WPS on your AirStation.

In a web browser's URL window, type the IP address of your Nfiniti wireless router (usually 192.168.11.1).



The username for your AirStation is "root". The default password is blank.



Click the button for "WPS Settings".

 A screenshot of the Buffalo WZR-AG300NH AirStation web interface. The page has a blue header with the Buffalo logo and "WZR-AG300NH" on the left, and "Wireless Access Point AirStation" on the right. Below the header is a navigation menu with tabs: "Setup", "INTERNET/LAN", "IPv6 Settings", "Wireless Config", "Security", "Gaming Ports", "Admin Config", and "Diagnostic". Under "Setup", there is a "Wizards & Overview" section with a "Logout" link. The main content area is divided into several sections:

- Basic Settings:** Includes "Run Internet Connection Wizard (Easy Setup)", "Wireless SSID & Channel", and "Wireless Encryption (WEP/TKIP/AES)".
- Quick Settings:** Divided into "Internet" (with "Internet Games (Port Forwarding)", "Intrusion Detector/Firewall", and "Wireless Multicast Rate") and "Other" (with "Update AirStation Firmware" and "Initialize AirStation").
- MODE Information:** Shows "Router Mode" with a "Change Mode" button.
- INTERNET Information (No INTERNET Cable):** Includes a "Refresh Current Information" button.
- WIRELESS:**
 - IEEE 802.11a (Auto / 40ch):** Shows SSID "0016016F01C1_A", Authentication "Open", and Encryption "Open".
 - IEEE 802.11g (Auto / 1ch):** Shows SSID "0016016F01C1_G", Authentication "Open", and Encryption "Open".
- At the bottom of the WIRELESS section, there are two buttons: "AOSS Setting Page" and "WPS Setting Page". The "WPS Setting Page" button is circled in red.

 On the right side, there is a "Wizards & Overview" sidebar containing an overview of the system and descriptions for the "Run Internet Connection Wizard (Easy Setup)", "Wireless SSID & Channel", and "Wireless Encryption (WEP/TKIP/AES)" wizards. The footer of the page reads "(C)2000-2006 BUFFALO INC. All rights reserved."

Uncheck “enable” by “WPS” and click *Apply*.

BUFFALO
WZR-AG300NH

Wireless Access Point
AirStation

Setup | INTERNET/LAN | IPv6 Settings | Wireless Config | Security | Gaming Ports | Admin Config | Diagnostic

WPS | AOSS | 11a | Security | Advanced | WMM | 11g | Security | Advanced | WMM | MAC Filter | Logout

WPS(WiFi Protected Setup)

WPS enable

External Registrar enable

Apply

AirStation PIN 12345670

Enrollee PIN

WPS Security Infomation [? HELP](#)

11a	WPS status	unconfigured
11g	WPS status	unconfigured

(C)2000-2006 BUFFALO INC. All rights reserved.

WPS(WiFi Protected Setup)

WPS
Specify WPS function.
The default is Enable.

External Registrar
Acceptance of request from External Registrar when WPS function is used. If disable is chosen, Internal Registrar is used. The default is Enable.

Warning
The AOSS connection disables External Register request.

AirStation PIN
Display AirStation's PIN code. New PIN code is created when Produce PIN button.

Enrollee PIN

For best results, download the latest firmware update for the WZR-AG300NH from Buffalo Technology’s website and install it before using the WZR-AG300NH with an Intel® Viiv™ technology-based PC.